




CONTROL PANEL PARTS

For Model: MH7115XBB5, MH7115XBQ5, MH7115XBZ5
(Black) (Designer White) (Almond)


OVER THE RANGE
MICROWAVE



1		Controller Sub Assy.
	4358841	Black Model
	4358842	White Model
	4358843	Almond Model
2		Control Panel
	4358552	Black Model
	4358551	White Model
	4358844	Almond Model
3	4358845	Bracket, Control
4		Key Membrane
	4358846	White Model
	4358847	Almond Model
	4358848	Black Model
5	4359237	PCB Sub Assy.
6	4358015	Screw
7	4358192	Screw

DOOR PARTS


For Model: MH7115XBB5, MH7115XBC5, MH7115XBZ5
(Black) (Designer White) (Almond)



1		Door Assembly
	4358561	Black Model
	4358722	White Model
	4358824	Almond Model
2		Frame, Door
	4358750	Black Model
	4358751	White Model
	4358827	Almond Model
3	4358752	Tape, Seal
4	4358546	Latch
5	4358607	Spring, Latch
6	4358820	Plate, Hinge
7		Panel, Door
	4358567	Black Model
	4358566	White Model
	4358834	Almond Model
8		Baffle, Door
	4358555	Black Model
	4358554	White Model
	4358835	Almond Model
9		Glass, Door
	4358836	Black Model
	4358837	White Model
	4358838	Almond Model
10		Handle, Door
	4358549	Black Model
	4358548	White Model
	4358839	Almond Model
11		Choke Cover
	4358558	Black Model
	4358557	White Model
	4358840	Almond Model
12	4358067	Screw
13	4358381	Screw

CABINET PARTS

For Model: MH7115XBB5, MH7115XBQ5, MH7115XBZ5
(Black) (Designer White) (Almond)



1		Outer Case
	4358926	Black Model
	4358925	White Model
	4358927	Almond Model
2	4358928	Mounting Bracket
3		Grille Vent
	4358562	Black Model
	4358851	White Model
	4358852	Almond Model
4	4358759	Bracket Front
5	4358760	Power Cord
6	4358761	Cover, Power Cord
7	4358383	Shelf Holder
8	4358816	Bracket, Grille
9	4358762	Screw
10	4358489	Screw
11	4358190	Screw
12	4158371	Probe
13	4358833	Rack

Following Parts Not Illustrated
4359377 Blower Plate

For Model: MH7115XBB5, MH7115XBQ5, MH7115XBZ5
(Black) (Designer White) (Almond)




1	4358059	Magnetron
2	4358772	Thermostat
3	4358774	Transformer
4	4158947	Capacitor
5	4358775	Thermostat
6	4358777	Motor
7	4358778	Bracket
8	4158827	H.V. Cable
9	4158923	H.V. Diodle-Cable
10	4358823	Lead Wire
11	4358780	Lead Wire
12	4358781	Plate, Bottom
13	4358782	Stirrer Fan Disk
14	4358783	Holder Disk
15	4158731	Ceramic Plate
16	4358156	Temp Hole Cap
17	4358489	Screw
18	4358192	Screw
19	4358376	Screw
20	4158747	Screw
21	4358188	Screw
22	4158212	Nut
23	4158213	Washer

LITERATURE PARTS

LIT4359224	Guide, Use & Care
LIT4358932	Instructions, Installation
LIT4359182	Tech Sheet
LIT4358520	Cookbook

INTERIOR PARTS


For Model: MH7115XBB5, MH7115XBQ5, MH7115XBZ5
(Black) (Designer White) (Almond)



1	4358784	Motor, Fan
2	4358564	Guide Suction
3	4358379	Blower Fan
4	4358785	Fuse Holder
5	4358704	Fuse
6	4358055	Push Nut
7	4358786	Air Duct
8	4358787	Motor, Ventilation
9	4358789	Cover, Lamp
10	4358790	Lamp, Holder
11	4158344	Oven Lamp
12	4158376	Motor Condenser
13	4358536	Guide Air
14	4158368	Base Thermostat
15	4358791	Cover, Connector
16	4358792	Filter
17	4359189	Lead Wire
18	4358192	Screw
19	4358190	Screw
20	4358376	Screw
21	4358191	Screw
22	4358015	Screw
23	4358064	Screw
24	4358825	Sensor
25	4358826	Sensor Box

LATCH BOARD PARTS


For Model: MH7115XBB5, MH7115XBC5, MH7115XBZ5
(Black) (Designer White) (Almond)



1	4358794	Board, Latch
2	4158940	Micro Switch
3	4358269	Micro Switch
4	4158941	Micro Switch
5	4358267	Micro Switch
6	4358795	Lever Monitor
7	4358271	Screw


VENTILATION PARTS

For Model: MH7115XBB5, MH7115XBC5, MH7115XBZ5
(Black) (Designer White) (Almond)



1		Base Plate
	4358930	Black Model
	4358929	White Model
	4358931	Almond Model
2		Cover Cooktop Glass
	4358765	Black Model
	4358533	White Model
	4358831	Almond Model
3	4358571	Glass, Cooktop Lamp
4	4358767	Cushion-Glass
5	4358768	Lead Wire Assy.
6	4358769	Cover, Wire
7	4158344	Oven, Lamp
8	4358853	Air Filter
9	4358790	Lamp Holder
10	4358829	Screw
11	4358190	Screw

INSTALLATION PARTS
For Model: MH7115XBB5, MH7115XBC5, MH7115XBZ5
(Black) (Designer White) (Almond)



1	4158541	Exhaust Adapter
2	4158319	Exhaust Damper
3	4158321	Toggle Bolt/Wings
4	4158326	Toggle Wing
5	4158323	Screw
6	4158315	Screw
7	4158314	Washer
8	4358924	Plate, Mounting Wing
9	4358011	Clamp
10	4358012	Bushing
11	4358935	Sheet-Top Cabinet Template
12	4358934	Sheet-Wall Template
13	4358188	Screw
14	4358192	Screw
15	4358010	Screw
16	4358933	Pin, Locking